





EN User Manual
DE PN: E15-57911AA001
 May 10, 2011 - v1.0
ES
FR **CE** **FC**



© 2011 by AKITIO - All Rights Reserved

SK-3500 U3+



- 1**
LED indicator: Blue = Power ON, status ready
Flashing Blue = Power ON, read/write access
LED-Anzeige: Blau = Gerät und Strom eingeschaltet
Blau blinkend = Datenzugriff (schreiben/lesen)
Indicador LED: Azul = ENCENDIDO, espera
Azul intermitente = ENCENDIDO, acceso de lectura y escritura
Voyant DEL : Bleu = sous tension, statut prêt
Bleu clignotant = sous tension, accès lecture/écriture
- 2**
USB 3.0 SuperSpeed port
USB 3.0 SuperSpeed Anschluss
Puerto de USB 3.0 SuperSpeed
Port USB 3.0 SuperSpeed
- 3**
FireWire 800 ports
FireWire 800 Anschlüsse
Puertos FireWire 800
Ports FireWire 800
- 4**
Power receptacle (DC +5V/2A)
Netzanschluss (DC +5V/2A)
Toma de alimentación (+5 VCC/2A)
Prise de courant (CC +5V/2A)
- 5**
ON/OFF switch
Ein-/Ausschalter
Commutador de ENCENDIDO y APAGADO
Interrupteur MARCHE/ARRÊT

